

Holder for Button or DoubleButton

Bracket to fix Button or DoubleButton on surfaces

Always at hand

Holder helps to install the panic button where it will be rapidly accessible in an emergency and makes using the remote control for scenarios even more convenient. The wireless device will remain portable: the button can be quickly detached from the holder and used as a key fob.

Designed by perfectionists

Holder design does not compromise the ergonomics of the button and provides a secure fit. It could be attached to a surface with two screws or on double-sided adhesive tape—thanks to the large, flat area, even such an installation method is reliable. [Button](#) and [DoubleButton](#) are attached and detached from the holder in one motion. No need to use any tools and waste time.

Tech Specs

Color	White/Black
Material	Plastic
Operating temperature range	From -10°C to +40°C
Operating humidity	Up to 75%
Dimensions	47.1 × 37.9 × 14.2 mm
Weight	3.5 g
Warranty	Replacement and repair within 24 months of the date of sale. If the device does not function properly, we recommend that you first contact the support service as technical issues can be resolved
Complete set	Holder for Button/DoubleButton Installation kit Quick Start Guide